


## These directions are for Day-Night RV Shade

Restraining the blind is not difficult however you will need to remove the blind from its mounting base. There are a number of different retainer styles, so you will need to examine yours to see what method is required to detach the blind.

Remove the shade assembly from the installation brackets: Raise the shade all the way to compress the fabric. Loosen the tab screw on the back of each mounting bracket. Tilt the back of the headrail down to remove the rail from the brackets (Figure 1). Place the shade assembly on a clean work surface. Note: If you have a steel bracket without the tab screw, the shade may be removed utilizing the same tilting action shown. (If they do not include the stringing needle then get one as well).



**Figure 1:** Loosen the tab screw and tilt the back of the headrail down to remove the shade assembly from the installation brackets.

**S**ome blinds are held up by a spring steel clip maybe an inch long. One side will have a lip on it, the other side does not. That lip is the key. What I did was take a heavy screwdriver and tried to wedge it between that lip and the top of the blind until it released allowing the blind to drop out. Did the same thing with the other end clip.



Once the blind is removed, rest it on a hard surface. Cut the strings from both hold-downs then proceed to remove the plastic end caps on all rails with a flat head screwdriver. Remove the bottom and top rails from the blind by sliding them off then slide the bottom section of the pleated shade from the center rail. The rails slide off horizontally, and may get hung up on a knob rivet, so be firm, it will eventually slide off. Once the blind is disassembled, proceed as follows.


In the top rail, the cord will be attached to a spring on each side. The cord coming from the left will run down through the left side of the night material. The cord coming from the right will run down through the right side of the night portion of the shade. The cords will cross in the center rail, so that the cord that runs down the left hand portion of the night shade, will cross over and run down through the right hand side of the day shade.

Do the same for the right hand side of the night shade. It will cross over in the center rail and run down through the left hand side of the day shade. Now the cord coming down through the right side of the day portion will once again cross in the bottom rail and exit out of the left hand side of the shade through the end cap, use a threader needle to thread the cords through the holes. Inspect the holes for any burrs or sharp edges as they may damage the cord. After threading the blind, assemble the top rail including plastic end caps.

Remember to stay within the ridges of the PVC. Insert center end caps. Thread the cord through the bottom end caps. There is a right and a left end cap; please check before threading. After inserting end caps, measure and cut cords to required length. After required length has been cut, see illustration on how to tie on the spring tension spool. **REMEMBER:** Reset the drop of your shade by tying the cord retainers where you need them to be and adjust the tension as needed by wrapping the cord around the cord retainers.

My experience suggests adjusting the blind to have sufficient tension to stay in place and no more. This will give you the ability to increase tension should the spring weaken with age and it also places less tension on the strings. If the string rubs against the blind mounting hardware it will fray and eventually break.







**Cut string loose from hold downs**



**Slide bottom rail from pleated blind**



**Starting at top rail, thread sting through holes as illustrated on diagram**



**Pleated blind with criss-cross cord pattern**

If the cords are not broken, you do not have to remove it. Cut the old cord from the spring and weld the ends of the new cord together using a lighter or match. Roll the joined cords between your fingers to create a smooth weld. Pull the old cord out new cord follow.

**[Venetian Blind Repair Shop](#)**

**Address: 1704 E 29th St.**

**Vancouver, WA 98663**

**Phone: 360-696-8308**